

TUTORIAL From GFD to Surfaces, Volumes and Reports calculation

From GFD to Surfaces, Volumes

DESCRIPTION

Use Survey data to create surfaces, volumes and manage reports infomation

GOAL

- How to use survey data to create surfaces
- How to use survey data for volumes calculation
- How to create reports

DATA

• Terracina.gfd





Import SURVEY data

FILE	HOME	VIEW	DRAW	EDIT	SURVEY	SUR	FACES	X-SECTIONS	CADA	ASTRAL	CLOUD	X•LIVE	OUTPUT		
Project	Scanner	TPS	Controller	D Scanner	X-PAD	Text	DWG/DXF		LE Survey	+ x Y Z ID point	Annotation	H→H Distance	Distance	Area	Angle
				data	Survey				data				object		_
Settin		Transfe	r			Im	port file					Info			

IMPORT FILE bar are the toolbar where find all the features related to data importation

Select **X-PAD Survey** to import survey file recorded in field with X-PAD Field software and select the job from the relative folder.





Survey data FILTERS

Proje	ct Manager	1
- 32	Surveys	1
	🔀 Main survey	1
	🔀 Terracina	1
Ē	Surfaces	
⊿ I⊾	Drawings	1
	Main drawing	
\subseteq	§ Sections groups	
	Point clouds (Registered)	1
	Point clouds (Not registered)	
<u>_</u>	Raster maps	1
	Orthophotos	
4	Projection planes	
	< ☆ None	
-	2 Clipping planes	
Ĩ	Clipping boxes	1
G	Plot boxes	
粛	Views	
0	>□ 10 11 0 4 - 2	
	 Project Manager	
B	Layers	
	Survey codes	
T	Filters	
ā	Report	

🗄 Export



From the **PROJECT MANAGER** select **FILTERS,** from entities deselect GNSS Bases and Measurements GNSS to hide this entities





New Surface



From the **SURFACES** menu select New empty surface and insert the name of the new surface.

New surface	×
Surface name	
surface	
	OK Cancel





New Surface – BREAK LINES



From **SURFACES** menu it is possibile to select Breakline or Boundary line contorno to be used in creating a surface.

It is possible to use an existing polyline or create new elements directly on the points of the current survey.

Select **Boundary external** to draw a contour line directly on the points of the current survey.





New Surface – Break Line

والمحالية المتحادث والمحالي المحالية المحالية المحالية المحالية المحالية المحالية المحالية المحالية المحالية ال







Build a new SURFACE

Puild surface			
sund surface			
Surface: surfa	ice		~
Surveys and Points clo	ud		
Name	Points	Elev.Min	
🖧 Terracina	702	[?	1
/		_	
		-	>
< Add Transformed Rem	nove	-	>
 Add Trans Add Options 	nove		>
 Add The Rem Build options 	nove		>
 Add Transformer Build options Iso hound any lines (#1) 	nove	Ver	>
< Add I Rem Build options Jse boundary lines (#1)	nove	Yes	>
< Add Transformer Add Transfor	nove	Yes	>
< Add Transformer Ren Build options Use boundary lines (#1) Check triangles side lenge	nove ti	Yes No	>
< Add Add Ren Build options Use boundary lines (#1) Check triangles side leng Remove neaks	nove gth Max side len	Yes No gth: 100.00	>
< Add The Rem Build options Use boundary lines (#1) Check triangles side leng Remove peaks	nove gth Max side len	Yes No gth: 100.00	>
< Add Add Rem Build options Use boundary lines (#1) Check triangles side leng Remove peaks Seporth surface	ti gth Max side len Peak angle	Yes No gth: 100.00 (*): 80	>
< <p>Add Transmission Removes a constraint of the second and the s</p>	nove gth Max side len Peak angle	yes No gth: 100.00 (*): 80 No	> 0m
Add Transformer Control of the second	nove gth Max side len Peak angle	Yes No gth: 100.00 (*): 80 No	> 0m
Add Transformer Removes Peaks	nove gth Max side len Peak angle	yes No gth: 100.00 (°): 80 No	> 0m

From **BUILD SURFACE** menu it is possible to select:

- Survey data to be used, in this case only the current survey *Terracina* will be visible.
- Breaklines or Boundary lines
- Check for the maximum triangles side lenght
- Remove peaks
- Smooth surface

Select boundary lies and **BUILD**





New Surface









New SURFACE - View

By elevation	Triangle sides			X	5	Build surface Style	s & colors
						Color options	
Fixed color	🞸 Slope symbols	Calculate *	Calculated volumes	Tools *	Delete data	Style:	Fixed color
V	Volu	umes	Util	ities		Green	



From the *VIEW* panel of the *SURFACES* menu it is possible to select:

- Color options of the surface, the option can also be selected during the built of the surface
- Triangle sides, to show the sides of the triangles of the surface
- Slop symbols





New SURFACE - View

By elevation Triangle sides		Slope direction symbols
Fixed color 🛛 🖉 Slope symbols	Calculate Calculated	Slope direction symbols
View	Volumes	I Surface: surface
	Q Q ∷ ⊦⊜	Symbol length (mm): 10.0 🛟
	WY LUP -	Display slope value
		Display direction value
	14 E	Text size (mm):
L.		Text style: Vefault

Selecting **Slope symbols** it is possible to show the value of the slopes of the surface with the relative slope direction





SURFACE Report

Info	Reports		Report	<
New	Survey	Triangles	POF surface	03/01/2018
Open	Topographic points	Show preview, print, export the report of Triangles.	301 Kbytes	17:10:40
Save	Reference points Reference points Reference TPS	Surface	🗀 🛅 ĝ↓ - 🗹	
Save as	Measurements GNSS	ව		
Import	Measurements Distance-Distance	Preview	📰 Project Manager	
Export	Measurements Alignment and offset		₿ Layers	
	Surface		Survey codes	
Close	Triangles			
Ontions	Volumes (summary)		Filters	
	Volumes (complete)		Report	
About X-PAD Office Fusion	REB22.013			
Exit			🛃 Export	

From *FILE* menu it is possible to select *REPORTS* to open the *REPORT MANAGER* and create reports related to:

- SURVEY
- SURFACE

All the REPORT can be viewed from the PROJECT MANAGER





SURFACE Report

8	Report Manager	ð ×
13 8 8 13 13 2 ∞ 2 0 0 0 1 × K 4 >	▶ ♀ ◎ ◎ ⊠	
Store priors Print PDF File XLSX file Other Send as Scale Margins Orientation Size First Previous Next page page	e Last page Find Page width Whole Close page	
Templates	Zoom Close	â
Triangles		•
	Triangles	
	First vertex Second vertex Third vertex Awax I N Z I N Z I N Z Awax	
	T T T	
	- 48487 - 45282 4238 - 7722 - 75584 427 4259 477 4223 1400 584 584 70277 - 11284 417 - 4669 4669 4217 4849 4859 4288 438 444 544 4468 - 4640 421 - 4549 - 17584 428 - 4889 12584 4247 5420 567	
	이었었는 "이상에 신과 수당되며 "이용에 신과 "이용에 신과 '이상의 '이상의 '신과' 부가고 사용점 '사용의 신과 수당과 '신과' 이상의 신과 '사용의 '이상의 '이상의' 신경의 분위 동생 문화 ·사용의 '이상의 신과 '사용의' 신과 '사용의' 신과 '신과' 시장의 '신화의 신화의 분위 ·	
	- 48년 · 188년 신과 · 18일 · 18g	
	· 1982년 · 1982년 2011 · 1982년	
	後288 - 486 (4) - 488 - 4707 - 4228 4) - 427 - 4480 4) - 482 - 440 4 - 440 - 472 41 - 473 4) - 428 - 448 - 476 4) - 478	
	48.347 H00.552 4.358 44.844 H50.553 4.259 77.722 H36.95 4.112 48.95 4.85 47655 H3644 4.77 14.269 4.058 4.058 4.254 44.444 H50.57 55.5 44.844 H51.68 4.275 H368 4.428 H368 4.254 44.47 14.558 4.279 55.5	
	- 1527 - 15251 - 158 - 4788 - 4289 - 428 - 458 - 428 - 428 - 428 - 427 - 527 - 4288 - 4788 - 428 -	
	· 색(m) · 1988) · 신제· · · · · · · · · · · · · · · · · ·	
	422201 487502 448 4248 45 4510 423 428 424 424 424 428 525 425 525 425 425 525 425 525 425 525 425 525 5	
	- 2700 - 4723 - 424 4844 - 4444 - 4423 - 4723 - 4735 - 443 - 443 - 443 - 443 - 443 - 443 - 444 - 444 - 444 - 445 - 443 - 443 - 443 - 443 - 443 - 444 -	
	- 1278 - 148475 488 4207 - 19888 4207 - 19888 455 425 428 4823 427 558 558 1284 - 1284 427 428 429 429 423 422 428 4284 4284 4284 4284 428 -1278 148475 488 - 1288 429 429 429 429 428 428 558 558 -1284 - 14848 429 428 128 42 488 488 429 429 429 429 429 429 429 429 429 429	
	1 18년 - 1788년 4월 - 1982년 - 1888년 48월 - 1889 - 1889 - 1889 - 1899 - 1899 - 1897 - 1899 - 4889 - 1789 - 1489 - 1789 - 439 - 4389 - 1889 - 1897 - 1317 - 1329 - 18438 - 4329 - 4329 - 1733 - 4379 - 4389 - 1837 - 437	
	····································	
	36564 イ田山の(山口の) 3687 イTLAB 4487 4321 4321 Documentalia 00/17/2719/33 00/17/2719/33 00/17/2719/33 00/17/2719/33 Indea Page 10/6 10/17/2719/33 00/17/2719/33 00/17/2719/33	
	NoAb Office Kulsen	
I O 🖉 🗓 🧠		>
Page 1 of 26	A4 (210mm x 297mm) 72%	++





SURFACE on Web Map

and the state of the second second



From **VIEW** menu it is possible to select **WEB MAP** to show the surface on web map







From **SURFACES** menu it is possible to select **CALCULATE** for the volume calculation, selecting from:

- **To Elevation:** calculate the surface volume according to an elevation
- **To Point**: calculate the surface volume according to the elevation of a topographic point
- **To Surface**: calculate the surface volume between two different surface
- **Reference plane**: calculate the surface volume according to a reference plane
- **Stockpile Pit**: calculate the volume between the surface and the perimeter surface



Volume calculation		4
Calculation settings		
Stockpile/Pit		
I Surface:	surface	
Min elevation:		-2.750m
Max elevation:		0.244m
Direction:	Surface to base	~
Calculation option	s	
Calculation mode:	By triangles	~
Cut swell factor:		1.000
Calculate weight		Yes
Weight (t/m³):		1.000

Selecting for example **Stockpile Pit** it is possible to select:

Direction:

- Surface to base
- Base to surface

Calculation Mode

- By triangles
- By regular grid
- REB-VB 22.013

Cut swell factor and Weight

	.	By triangles	
Surface to base		By regular grid	
Base to surface		REB-VB 22.013	









From REPORT button you can access to the REPORT MANAGER





Save volume calculation	
Enter a name to the calculation of volume and a description.	Save volume calculation Specify if save the reference surface and the elevation difference surface.
Volume name: Stockpile_Pit Description: Stockpile/Pit	Create elevation difference surface Yes Surface name: Difference stockpile surface
	Create reference surface No
Next	c Back OK Cancel

From **SAVE** button it is possible to access to Save Volume Calculation menu, where it is possible to insert **name**, create a **elevation different surface** or **reference surface**









VOLUME Reports

Info	Reports		Report	<
New	Survey	Volumes (summarv)	PDE surface	05/01/2018
Open	Topographic points	Show preview, print, export the report of Volumes summary.	1.2 Mbytes	09:24:31
	Reference points		vol_im	05/01/2018
Save	Measurements TPS		42 Kbytes	09:16:21
Save as		হ	vol_summary	05/01/2018
Import		Preview	A2 Kbytes	09:16:07
	Measurements Distance-Distance		🚘 🛅 ĝ↓ - 🖂	
Export	Measurements Alignment and offset			
	Surface		📰 Project Manager	
Close	Triangles		- Charles	
	Volumes (summary)		⊖ Layers	
Options	Volumes (complete)		Survey codes	
About X-PAD Office Fusion	REB22.013		Eilter	
Exit			Finters	
			Report	

From *FILE* menu it is possible to select

REPORTS to open the **REPORT MANAGER** and create reports for

Export

- Volumes (summary)
- Volumes (complete)

With the possibility of including an image related to the surface

VOLUMES (summary) Reports

22 Man	Report Manager	a x
The store options report Options PFint PDF File XLSX file Other export Send as cale Scale Margins Drientation Size First Previous Nav Report Print & Export Print & Export Print & Export Page setup Nav Nav	et page Last page Find Page width Whole page Zoom Close	
Templates - [Volumes]		
Volumes_Summary		
Volumes_SummaryImage	Volumes (summary)	
	Volumes (summary)	
	Results Volumes Weights Cut 1115167 ³ 111516	
	Fil 191944th 191944th	
	Surfaces Totals Cut surface Fill surface Surface 2D 69466[31m ² 9142/71m ² 60221[34m ²]	
	Surface 2D 66475.58m ² 9147/58m ³ 60383.00m ³	
	Deciminalda 05/01/2014-054 Decipila,21 kga 1/1	
		3
Page 1 of 1	A4 (210mm x 297mm) 72% -	+++++++

VOLUMES (complete) Reports

Main			Report Manager																a ×								
Store Options	Print PDE File	XI SX file	Other	Send as	Scale Margin		In Size	K K	t Prev	(•	N Last page	Q	Q Page wi	dth Whol												
report			export *					S./ pa	ge pa	ige					page												
Report Templates - (Volumes	calculation	Print & Ex	port		р Р	ige setup				Navig	gation			2	oom	Close											^
	omplete																										•
Volumes_C	ompletelma	ge																									
														Vo	lumes	(com	olete	.)									
								First verte	x			Second v	ertex			Third vert	ex			Area	is		Volu	umes			
							E	N	Z 1	Z 2	E	N	Z 1	Z 2	E	N	Z 1	Z 2	Area Cut 2D	Area Cut 3D	Area Fill 2D	Area Fill 3D	Vol. Cut	Vol. Fill			
							m -70.727	m -171.274	m -0.157	m -0.157	m -68.347	m -160.592	m -0.238	m -0.167	m -80,269	m -167.223	m -1.100	m -1.100	m²	m²	m ² 55.78	m ² 56.02	m³	m ³			
							-92,291	-155,690	-0,070	-0,049	-93,139	-156,144	-0,060	-0,047	-89,646	-163,373	-0,064	-0,064			3,86	3,86		0,04			
							-92,019	-155,544 -155,544	-0,073	-0,045	-89,646	-163,373 -155,690	-0,064 -0,070	-0,064 -0,049	-87,075 -89,646	-152,896	-0,131	-0,065			22,50	1,24		0,71			
							-93,139 -80,269	-156,144 -167,223	-0,060	-0,047	-99,246 -77,720	-159,415	0,012	0,012	-89,646 -89,646	-163,373 -163,373	-0,064	-0,064	53.73	54.15	27,79	27,79	13.02	0,12			
							-68,347	-160,592	-0,238	-0,167	-80,269	-167,223	-1,100	-1,100	-69,016	-160,322	-0,233	-0,233			3,83	3,84		0,10			
							-80,269 -80,269	-167,223 -167,223	-1,100 -1,100	-1,100	-80,269 -76,809	-167,223	-1,100 -0,179	-1,100 -1,000	-69,016 -69,016	-160,322 -160,322	-0,233	-0,233	44,59	44,75			12,20				
							-76,809	-157,177	-0,179	-1,000	-77,720	-156,810	-0,172	-0,899	-80,269	-167,223	-1,100	-1,100	5,21	5,23	0.52	0.52	2,69	0.03			
							-59,958	-165,128	-0,304	-0,263	-59,028	-164,597	-0,230	-0,264	-59,844	-164,246	-0,310	-0,262			0,32	0,32		0,03			
							-70,727 -70,727	-171,274 -171,274	-0,157 -0,157	-0,157 -0,157	-59,958 -59,844	-165,128 -164,246	-0,304 -0,310	-0,263 -0,262	-59,844 -68,258	-164,246 -160,630	-0,310 -0,238	-0,262 -0,158			4,40 49,24	4,40 49,25		0,13 2,10			
							-41,895	-173,607	-0,453	-0,352	-39,867	-172,468	-0,487	-0,373	-41,884	-171,633	-0,464	-0,349			2,00	2,00		0,22			
							-51,647	-179,084	-0,288	-0,288	-41,895	-173,607	-0,453 -0,464	-0,352	-41,884	-168,430	-0,464	-0,349 -0,286			9,60 44,48	9,60 44,48		3,01			
							-51,327	-169,419	-0,359 -0.359	-0,277	-50,674	-169,040	-0,365	-0,279	-50,577	-168,042	-0,368	-0,279			0,31	0,31		0,02			
							-61,262	-175,198	-0,274	-0,274	-51,327	-169,419	-0,359	-0,277	-51,272	-167,759	-0,364	-0,275			8,09	8,09		0,46			
							-61,262 -50,674	-175,198 -169,040	-0,274 -0,365	-0,274 -0,279	-51,272 -49,626	-167,759 -168,430	-0,364 -0,374	-0,275 -0,286	-59,028 -50,577	-164,597 -168,042	-0,317 -0,368	-0,264 -0,279			44,64 0,49	44,64 0,49		2,11 0,04			
							-50,674	-169,040	-0,365	-0,279	-51,327	-169,419	-0,359	-0,277	-51,647	-179,084	-0,288	-0,288			3,09	3,10		0,17			
							-50,674	-169,040	-0,365	-0,279	-51,647	-179,084	-0,288	-0,288	-49,626	-168,430	-0,288	-0,286			47,09	47,05		0,29			
							-68,258 -59,844	-160,630 -164,246	-0,238 -0,310	-0,158 -0.262	-68,239 -59.028	-160,549 -164,597	-0,239 -0,317	-0,158 -0.264	-68,347 -55.374	-160,592 -155.515	-0,238 -0.354	-0,167 -0.256			4.35	4.35		0.29			
							-59,844	-164,246	-0,310	-0,262	-55,374	-155,515	-0,354	-0,256	-58,892	-156,892	-0,322	-0,255			12,28	12,28		0,88			
							Document34																05/	01/2018 10:48			
							stockpile_Pit								V								Pa	ge 1/212			
															<mark>∕</mark> ₀ X-F	AD Office Fus	on										
		_																							1		J
Page 1 of 212		1	<																					A4	(297mm x 21	0mm) 101%	 +

For the Reports editing follow the tutorial:

9_Tutorials_CustomReports